

QUICK•STEP® REPAIR KIT



Product description

Repair kit for damaged laminate, vinyl or parquet floors.

Packaging quantity: 1

Contents: 1 melter, 1 cleaning comb, 1 grey sanding pad, 1 green/white pad, 7 wax blocks and 1 instruction manual.

Applications

Quick-Step® laminate, LIVYN and Parquet stand for quality. The laminate floor consists of a hard core of a high-quality HDF board, which makes the Quick-Step® floor extremely wear and impact resistant. Quick-Step® is also a laminate with an exceptionally resistant wear layer. Quick-Step® Parquet floors are composed of 100% natural materials and treated with lacquer or oil for optimal protection.

When a very sharp object falls on the floor from a fair height (e.g. the point of some scissors), it is sometimes unavoidable for the floor to sustain slight damage. The Quick-Step® Repair kit can be used to repair the light damaged area.

Specifications

- √ Matching repair
The Quick-Step® Repair Kit offers a matching solution for every Quick-Step® Laminate and Quick-Step® Parquet floor. This enables you to optimise the colour to the shade that best matches the damaged plank.
- √ Easy and fast
The room looks nicely finished, without having to change the damaged plank.
- √ A complete repair kit
All the elements needed for repairing every Quick-Step® floor are available in one and the same kit.

Instructions for use

1). Preparation:

Proper preparation is important. Clean the damage on the floor first and make sure it is free from dust, oil, wax and grease.



2). Choose your colours:

Choose your colours according to the recommendations on www.quick-step.com



3). Melt and Mix

In the matching table: shades between brackets () are not always necessary (depending on the surface area). Notice that they change the colour so much that you only need a very small amount of it. For the grains: use a little more or even only the darker brackets.



4). Filling



5). Levelling:

Use the sharp edge of the filler to scrape off excess material.



6). Precise adjustment:

For a precise adjustment of the wood pattern you can scratch the area to be restored with a pointed item and fill it with a darker colour.



7). Degrease using the grey sanding pad



8). Adjust the gloss level:
Use the green side of the green/white pad to make the area more glossy.
Use the white side to make it more matt.



For more information, see www.quick-step.com or check out our manual on YouTube:
<http://www.youtube.com/watch?v=18L5pv1VL0E>.